

# **DuPont™ AirGuard® Control installation**

NBS: P10 310 Also: H20, H21, H30, H31, H40, H51, H92, K10, K21 M30

For additional information on our product(s) and guidance on how to use them you may wish to refer to our step by step Installation Guide and videos. This and other useful information is on our web site:

# www.building.dupont.co.uk

For help with a project please contact the DuPont Building Knowledge Centre. (Contact details can be found at the end of this Installation Sheet).

**Air/Vapour Control Layer (AVCL)** to EN 13984:2013 shall be **DuPont™ AirGuard® Control** as supplied by DuPont Performance Building Solutions, HERE, 470 Bath Rd, Arno's Vale, Bristol. BS4 3AP. UK

#### Storage

Rolls of DuPont™ AirGuard® Control should be stored palletised or on their sides on a smooth clean surface, under cover and protected from direct sunlight.

#### Damage

Care should be taken when handling the membrane to prevent tears and punctures occurring. Small punctures can be repaired with Tyvek® Acrylic Tape (2060B). Large areas should be replaced with new material.

#### Orientation

DuPont™ AirGuard® Control is installed onto the internal side of the building envelope with the smooth blue side and logo facing into the building interior. The membrane may be laid either horizontally or vertically to suit the substrate.

## Fixing - to timber

Initial fixing of DuPont™ AirGuard® Control should be made by using a combination of Tyvek® Double Sided (acrylic) Tape and stainless-steel staples. The membrane should be permanently fixed with a timber batten, which will also seal the staple penetrations.

Where battens over the membrane are not being used Tyvek® Butyl Tape (double sided) should be applied to the stud/noggin beforehand and the staple fixed through. Subsequent fixings for the internal lining should also be made through the Tyvek® Butyl Tape.

# Fixing - to masonry

DuPont™ AirGuard® Control may be fixed to masonry with a suitable anchor fixing system or a masonry nail/screw and EPDM rubber washer. Fixings should be at maximum 500mm centres. Tyvek® Double Sided (acrylic) Tape may be used to fix the membrane in addition to the mechanical method. For airtightness, Tyvek® Butyl Tape (double sided) should be used at fixing points where a compressible washer (eg. EPDM) is not employed. A Primer can be applied to chalky or porous masonry to seal the surface and improve adhesion before applying adhesive tape.

#### Fixing - to steelwork (SFS)

Initial (temporary) fixing of DuPont™ AirGuard® Control may be made with continuous strips of Tyvek® Double Sided (acrylic) Tape. These should be supplemented with mechanical fixings through to the steel structure, where suitable drill-tip or self-tapping screws may be used. A rubber or EPDM washer should sit between the screw head and the membrane for air sealing purposes and screw fixings should be spaced vertically at 500mm centres on every stud (typical 600mm centres). Security of the AVCL can also be made by the retrospective installation of battens or lining brackets/channels.

# **Rainscreen Cladding Applications**

DuPont™ AirGuard® Control may be fixed to the external face of a cement bonded particle board, OSB or ply sheathing, using a combination of Tyvek® Double Sided (acrylic) Tape and stainless-steel staples. DuPont™ AirGuard® Control may also be secured by fixing through the sheathing to the underlying structure using suitable drill-tip or self-tapping screws. See Fixing - to steelwork (SFS) above.

In many cases, the retrospective fixing of timber battens or metal brackets (& insulation) will provide the principle security for the membrane. Care should be taken to ensure these components are fixed tightly over the membrane to avoid water ingress. If in doubt Tyvek® Butyl Tape may be used between the component and the membrane.

Note: The insulation, brackets/battens and external protection layers should be applied as soon as possible to avoid damage to the membrane.

# **Fixing to insulation**

Fix DuPont™ AirGuard® Control to rigid insulation with a proprietary expanding insulation fixing anchor at maximum 500mm centres. Penetrations made by wall ties or cladding brackets must be made good with either Tyvek® Acrylic Tape (2060B) or Tyvek® FlexWrap EZ.

## Laps

Maintain 100mm laps between each sheet and seal with Tyvek® Acrylic Tape (2060B) or Tyvek® Double Sided (acrylic) Tape.

## **Detailing**

Cover entirely the inside face of the roof or wall, ensuring maximum coverage. Maintain continuity at all adjacent walls, floors and roof junctions and seal with Tyvek® Acrylic Tape (2060B) or Tyvek® Double Sided (acrylic) Tape.

# Windows/doors/loft hatches

DuPont™ AirGuard® Control should be sealed tight against the frame with Tyvek® Acrylic Tape (2060B) or Tyvek® Double Sided (acrylic) Tape. Internal corners should be made good with Tyvek® AirGuard® Tape or Tyvek® FlexWrap EZ. Tyvek® Plastering Tape may be used for all the window sealing work, if plaster or render is later to be applied.

## **Penetrations**

All penetrations through DuPont<sup>™</sup> AirGuard<sup>®</sup> Control (lighting, pipework, wiring, etc.) should be sealed with Tyvek<sup>®</sup> FlexWrap EZ. Fixings to timber, masonry or steelwork may be sealed with Tyvek<sup>®</sup> Butyl Tape.

# Batten space/Service void

The internal lining (plasterboard, etc.) can be spaced off DuPont™ AirGuard® Control to create a services void. This will help to avoid penetrations through the membrane by electrical sockets, light fittings, etc. Timber battens of minimum 25mm may be used for this. To assist with air-sealing, Tyvek® Butyl Tape can be applied behind the batten beforehand.

## **Light fittings**

Where no services void exists, a sealed enclosure should be formed over light fittings. The enclosure must be sealed to the membrane using Tyvek® Butyl Tape or Tyvek® Acrylic Tape (2060B). Wiring penetrations must be sealed as much as possible using Tyvek® FlexWrap EZ. Where downlights are specified the preference is to use sealed, low energy (LED) units with F Capped approval, allowing continuous thermal insulation over the light unit. If halogen units are used, they should have an F Capped Approved loft cap fitted above.

# Fire regulations

DuPont<sup>™</sup> AirGuard<sup>®</sup> Control has Fire Classification E in accordance with EN 13501-1. Care should be taken to determine suitability of this membrane for the intended application, with specific regard to building height and proximity to boundary. Users/specifiers should refer to their regional regulatory guidance documents in case there are any requirements or variations that may restrict the use of this product.

Video installation link: https://www.dupont.co.uk/resource-center.html?BU=pbs&restype=video

# **DuPont Performance Building Solutions**


HERE 470 Bath Rd Arno´s Vale Bristol UK BS4 3AP

0117 452 9050

Option 1: Technical (Building Knowledge Centre)

Option 2: General Enquiries

Technical enquiries: tyvek.construction@dupont.com





Recommendations as to methods, use of materials and construction details are based on the experience and current knowledge of DuPont and are given in good faith as a general guide to designers, contractors and manufacturers. This information is not intended to be a substitute for any testing you may need to conduct to determine, for yourself, the suitability of our products for your particular purposes. This information may be subject to revision as new knowledge, regulations and experience becomes available since we cannot anticipate all variations in actual end-use conditions. DuPont makes no warranties and assumes no liability in connection with any use of this information. Nothing in this publication is to be considered as a licence to operate under a recommendation to infringe any patent right.

Tyvek® construction membranes are manufactured by DuPont under an ISO 9001: 2015 Quality Assurance System.

DuPont™, the DuPont Oval Logo, and all trademarks and service marks denoted with ™, <sup>SM</sup> or ® are owned by affiliates of DuPont de Nemours, Inc. unless otherwise noted. © 2024 DuPont.